




Clear and Simple Quick Start Guide


Alcatel IDOL™ 5

Getting to Know your Alcatel IDOL™ 5




Phone Setup


1. Place the SIM tool in the hole next to the SIM/microSD tray and push until the SIM tray pops out.



2. Hold the nano-SIM card with the cut corner to the bottom right and insert into tray. If applicable, hold microSD card (not included) with ridge to the left and insert it into the tray.



3. Carefully close the SIM tray.




WARNING: Only use a standard nano SIM card from your service provider.

Touch screen

Navigating your phone


- Use your finger tip to tap the screen.
- Use quick flicks of your finger on the touch screen to swipe up, down, left, and right.
- To return to the previous screen, tap **Back** <.
- Tap **Home** ○ at any time to return to the main home screen.
- Tap **Recent apps** □ to access recently viewed apps.
- Tap **Apps** □ to access applications on your phone.



Notifications panel

To access alerts, including new messages, emails, and software updates:

- Tap the top of the home screen and drag your finger down to view the Notifications panel.
- Swipe right or left to clear individual notifications or tap **CLEAR ALL** to clear all.
- With the Notifications panel open, tap the top of the screen again and drag down to see the Quick Settings menu.
- Tap **⚙️** to access the complete Settings menu.



Personalize


Set wallpaper

- To change your home or lock screen wallpaper, press and hold a blank part of the home screen and tap **WALLPAPERS** 🖼️.
- Select a wallpaper and tap **Set wallpaper** ✓ to set it. You can also tap **My photos** 📷 for additional options.



Add to home screen

- To add app shortcuts, tap **Apps** □, press and hold the desired app, and drag it to the home screen.
- To add widgets, press and hold on a blank section of the home screen and tap **WIDGETS** ⚭, press and hold the desired widget and drag it to the desired location on the home screen.



Organize home screens

- To move widget or app shortcut, press and hold it and then drag it to a new location. To delete it, drag it to "X Remove".
- To create a folder, press and hold an app shortcut and drag it on top of another and release.
- To rename a folder, press the folder title to type a new name.
- To make additional changes to home screen, e.g. changing grid view, icon size, and text, press and hold a blank section of the home screen and tap **HOME EDIT** 🛠️.


Calls and Voicemail

HD voice

Enjoy clearer conversations and reduced background noise with HD Voice*.


Make a call

1. From the home screen, tap **Call** ☎️.
2. Enter a name or phone number by using one of the following options:
 - 📞: To manually enter a phone number.
 - ★: To choose from frequently called contacts.
 - 🕒: To choose from a list of people who you have recently called or have called you.
 - 👤: To make a call from your contacts list.




Check voicemail

1. From the home screen, tap **Call** ☎️, then tap **📞**.
2. Press and hold **1**.



Call waiting

- Call waiting allows you answer a second call while you are on an existing call. While on a call, you will hear a tone if another call comes in.
- Tap the incoming call to answer.
 - Tap **🔀** to switch between active calls.
 - Tap **👤** to merge calls.
 - Tap **🔴** to end a call.



*To experience Cricket HD Voice, both callers must have a compatible HD Voice capable smartphone and make the call over Cricket's LTE Network or a compatible network. Cricket's LTE coverage is not equivalent to its overall network coverage. HD Voice calls made on a compatible device and on the LTE network may not experience an HD Voice connection at times of network congestion. Other carriers' networks may interoperate with Cricket's LTE network to support an HD Voice call.

Text and picture messaging


Send a text message

1. From the home screen, tap **Messaging** 📧.
2. Tap **New message** ✉️ to start a new text message.
3. In the **To** field, enter a number or a contact name or tap **Contacts** 👤 to access your contacts.
4. Tap the **Type message** field and enter your message.
5. Tap **Send** ➤ to send the message.



Send a picture message

1. Follow steps 1-4 above.
2. Tap the **Paperclip** 📎.
3. Tap **Pictures** 🖼️ and select desired picture or tap **📷** to take a picture to attach.
4. Tap **Send** ➤ to send the message.



WARNING: Please don't text and drive.

More information

On the web

Detailed support information including device specifications and troubleshooting are available at www.cricketwireless.com/support/devices.

On the phone

- Call Customer Care at **1-855-246-2461** or
- Dial **611** from your cell phone

Accessories

For more information about accessories, please visit your local Cricket store or go to www.cricketwireless.com/shop/accessories.



Note: Store and online inventories may vary.

Product meets FCC Radio Frequency Exposure Guidelines—FCC ID 2ACCA021. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

© 2017 Cricket Wireless LLC. All rights reserved. Cricket and the Cricket logo are registered trademarks under license to Cricket Wireless LLC. Other marks are the property of their respective owners. microSDHC logo is a trademark of SD-3C, LLC.

Alcatel is a trademark of Alcatel-Lucent and is used under license by TCL Communication Ltd. © Copyright 2017 TCL Communication Ltd. All rights reserved. TCL Communication Ltd. reserves the right to alter material or technical specification without prior notice.

IDOL 5 is a trademark of TCL Communication LTD. © 2017 TCT Mobile Limited. All rights reserved.

All "Signature" ringtones embedded in this phone have been composed, arranged and mixed by NU TROPIC (Amar Kabouche).




CJB37JC01AAA
Printed in China

Email

Email setup (Gmail™, Yahoo!®, etc.)

1. From the home screen, tap **Apps** □ > **Email** ✉️.
2. Enter your email address and tap **NEXT** ➤ and enter your password and then tap **NEXT** ➤ again.
3. Confirm email account settings and tap **NEXT** ➤.
4. Enter your name which will be displayed on outgoing mails, and then tap **FINISH** ➤.



Note: To set up corporate email, contact your IT administrator.

Create and send an email message

1. From the home screen, tap **Apps** □ > **Email** ✉️.
2. To compose a new message, tap **Compose** ✉️.
3. Tap the **To** field and enter email address or name or tap **Contacts** 👤 to access your contacts.
4. Enter a subject and email message.
5. To attach files to the email message, tap the **Paperclip** 📎 and make your selection.
6. Tap **Send** ➤ to send the message.



Cricket Apps & Services

These services make using Cricket even better and easier.



myCricket: Check account balance, make a quick payment, view usage and access support from the palm of your hand.



Visual Voicemail: Quickly view, access and play back of your voicemail messages. Easily save important numbers to your Favorites list and respond to messages by calling back or texting.




Deezer: Listen on-the-go with ad-free streaming music, download your favorites to your phone, and get customized playlists based on your preferences.

Apps on Google Play™

You can install apps from Google Play Store.

Access Google Play


1. From the home screen, tap **Play Store** 📺.
2. Enter your existing Google account or create one following the steps on the screen.



Navigate Google Play

From Play Store, there are multiple ways to find apps, games, and more:

1. Tap a category to browse popular apps, games, movies, and music organized by popularity or category.
2. Tap **Search** 🔍 to search the Play Store for a specific game or app.
3. To install, tap the app and follow instructions. Once installed, you will see a notification in the Notifications panel. Open the app from this notification or by locating the app in **App list** 📁.



Camera and video


Take a picture

1. From the home screen, tap **Camera** 📷.
2. Swipe the screen to select different modes.
3. Tap the **⚙️** in the upper left corner and tap **Settings** to display camera settings.
4. Zoom in and out by pinching with your fingers.
5. Tap the **Shutter button** 📷 or press the **Volume Keys** to take a photo.



Take a video

1. From the home screen, tap **Camera** 📷. Swipe the screen and select **Video** mode. Tap **📷** to start and **🔴** to stop recording.



View pictures

1. From the home screen, tap **Apps** □.
2. Tap **Gallery** 🖼️.



Send a picture

1. In Gallery, tap a picture and then tap **Share** 📎.
2. Choose to send via text messaging or email, and more.

Note: A Google Wallet™ payment method is required to purchase apps.

Unique Alcatel Features

Now Key


Instantly launch commonly-used tasks, or customize to launch your favorite app, with one press of the Alcatel-exclusive NOW key located conveniently on the right side of your IDOL 5.

1. From the home screen, tap **Apps** □.
2. Tap Settings, then Display.
3. Tap Trigger App to choose an application to quick launch.
4. Tap Trigger Func to choose the 3 common tasks you would like the Now Key to present when pushed.
5. Tap Do Nothing to turn off the Now Key.

Alcatel Music App with Deezer™ from Cricket

Play your favorite tunes, create playlists, stream up to 40 million tracks and sing along to your favorite song with Music and Deezer from Cricket integration.

1. From the home screen, scroll right.
2. Tap **Music** 🎵.
3. Tap a Playlist bubble 🎵 to quickly open your favorites, most played, recently played and other playlists.
4. Tap **DEEZER** and then **MY MUSIC** to log into your Deezer from Cricket Account*.
5. At the top of the screen, tap **🎵** to see your Playlist bubbles, tap **DEEZER** to access your music and featured Deezer playlists, tap **🌐** to view your online and offline music library.
6. Tap **🔍** to search for music on your phone. If you are logged into Deezer, tap **SEARCH ONLINE** to extend your search to Deezer content.



*Deezer account and subscription required.

Unique Alcatel Features

Reversible Display

Activate reversible display so your IDOL 5 is always right side up no matter how you pull it out of your pocket or purse.

1. From the home screen, tap **Apps** □.
2. Tap Settings, then Display.
3. Tap Reversible Rotate toggle to slide it to the right.

Advanced Camera Features

Take the perfect picture the first time, every time, with the IDOL 5 and features like:

- Enhanced sensors and extra-large pixels for richer pics.
- Image stabilization so your snaps are not blurry.
- LED flash on both front and back cameras for the best pics and selfies in low light.

Exciting new camera modes let you add your personality.

To access camera modes:

1. From the Camera application, tap the **⚙️** in the upper left corner.
2. Select desired camera or video mode.

Fast-charging with Pump Express™ Plus 2.0 cuts the time it takes to charge your Idol 5 in half!*

Virtual Reality (VR) Ready

The Alcatel IDOL 5 is optimized for VR with a fully-immersive Alcatel VR launcher, high-end VR content from Lifestar, and pre-loaded VR social network vTime. Enjoy this full VR experience with Alcatel UNI360 goggles (sold separately).



*As compared to conventional charging without Pump Express compatibility.

